


Program and memory layout

- By convention the layout is: 7fff ffff
 - Note that only half of the addressing space is taken by user
Other half is O.S.



Procedures

- Procedures/functions are the major program structuring mechanism
- Calling and returning from a procedure requires a **protocol** between *caller* and *callee*
- Protocol is based on conventions

Procedures/Functions -- Protocol


- Each machine (compiler?) has its own set of protocol(s)
- Protocol: combination of hardware/software
 - e.g., “jal” is hardware
 - use of register \$29 as \$sp is software
- Protocol: sequence of steps to be followed at each call and each return
 - controlled by hardware and/or software
- In RISC machines
 - hardware performs simple instructions
 - software (compiler/assembler) controls sequence of instructions

Program stack

- Each executing program (process) has a *stack*
- Stack = dynamic data structure accessed in a LIFO manner
- Program stack automatically allocated by O.S.
- At the start of the program, register \$sp (\$29 in MIPS) is automatically loaded to point to the *first empty slot* on top of stack
 - After that it will be your responsibility to manage \$sp
- *By convention, stack grows towards lower addresses*
 - to allocate new space (i.e., when you *push*), decrement \$sp
 - to free space on top of stack (*pop*), increment \$sp


Push operation

- *push* adds an item on top of stack
 - one instruction to manipulate the data, e.g. “sw \$6,0(\$sp)”
 - one instruction to adjust the stack pointer e.g., “subu \$sp,\$sp,4”



Pop operation

- *pop* removes the item on top of stack and stores it in a register
 - one instruction to adjust the stack pointer e.g., “`addu $sp,$sp,4`”
 - one instruction to manipulate the data, e.g. “`lw $8,0($sp)`”



Procedure call requirements (caller/callee)

- Caller must pass the return address to the callee
- Caller must pass the parameters to the callee
- Caller must save what is in *volatile* (registers) that could be used by the callee
- Callee must save the return address (in case it becomes a caller)
- Callee must provide (stack) storage for its own use
- Caller/callee should support recursive calls

Mechanism

- Registers are used for
 - passing return address in \$ra
 - jal target
 - passing a small number of parameters (up to 4 in \$a0 to \$a3)
 - keeping track of the stack (\$sp)
 - returning function values (in \$v0 and \$v1)
- Stack is used for
 - saving registers to be used by callee
 - saving info about the caller (return address)
 - passing parameters if needed
 - allocating local data for the called procedure

Procedure calls and register conventions

| Register | Name | Function | Comment |
|----------|----------------|---------------------------------|--------------------------|
| \$0 | Zero | Always 0 | No-op on write |
| \$1 | \$at | Reserved for assembler | Don't use it |
| \$2-3 | \$v0-v1 | Expr. Eval/funct. Return | |
| \$4-7 | \$a0a3 | Proc./func. Call parameters | |
| \$8-15 | \$t0-t7 | Temporaries; volatile | Not saved on proc. Calls |
| \$16-23 | \$s0s7 | Temporaries | Should be saved on calls |
| \$24-25 | \$t8-t9 | Temporaries; volatile | Not saved on proc. Calls |
| \$26-27 | \$k0-k1 | Reserved for O.S. | Don't use them |
| \$28 | \$gp | Pointer to global static memory | |
| \$29 | \$sp | Stack pointer | |
| \$30 | \$fp | Frame pointer | |
| \$31 | \$ra | Proc./func return address | |

Who does what on a call (one sample protocol)

- Caller
 - Saves any volatile register (\$t0-\$t9) having contents that need to be kept
 - Puts up to 4 arguments in \$a0-\$a3
 - If more than 4 arguments, pushes the rest on the stack
 - calls with jal instruction
- Callee
 - saves \$ra on stack
 - saves any non-volatile register (\$s0-s7) that it will use

Who does what on return

- Callee
 - restores any non-volatile register (\$s0-\$s7) it has used
 - restores \$ra
 - puts function results in \$v0-\$v1
 - adjusts \$sp
 - returns to caller with “jr \$ra”
- Caller
 - restores any volatile register it had saved
 - examines \$v0-\$v1 if needed

Example of a call sequence

- Assume 2 arguments in \$t0 and \$t3 and we want to save the contents of \$t6 and \$t7

```
move    $a0,$t0        #1st argument in $a0
move    $a1,$t3        #2nd argument in $a1
subu    $sp,$sp,8      #room for 2 temps on stack
sw      $t6,8($sp)     #save $t6 on stack
sw      $t7,4($sp)     #save $t7 on stack
jal     target
```

- Assume the callee does not need to save registers

```
target: sw  $ra,0($sp)  #save return address
        subu $sp,$sp,4  # on stack
```

Return from the previous sequence

- The callee will have put the function results in \$v0-\$v1

```
addu    $sp,$sp,4           #pop
lw      $ra,0($sp)         #return address in $ra
jr      $ra                #to caller
```

- The caller will restore \$t6 and \$t7 and adjust stack

```
lw      $t6,8($sp)
lw      $t7,4($sp)
addu    $sp,$sp,8
```

Factorial, The Logic

- Logic of call:
 - Put argument in register a0
 - Call procedure
 - Grab result from v0
- Logic of Operation
 - Make a place on the stack
 - Save the argument and return address
 - Decrement the argument
 - Check if recursion is done
 - If not, recurse again
 - If so, compute the result into \$v0
 - Grab return address
 - Restore stack
 - Return

```
li $a0,5
jal fact
sw $v0, ...
```

$$\$v0 = \$a0 * (\$a0 - 1)!$$

Factorial, The Code

```
fact:  subu $sp,$sp,8      #create 2 spaces on stack
      sw   $ra, 8($sp)    #push return address
      sw   $a0,4($sp)     #push argument
      addi $a0,$a0,-1     #decrement argument
      beqz $a0,base      #is recursion done?
      jal  fact          #recurse
      j    done          #v0 contains a0!
base:  li   $v0,1         #initialize v0
done:  lw   $a0,4($sp)    #get argument back
      mult $v0,$a0       #figure next term
      mflo $v0           #grab result & ready for return
      lw   $ra,8($sp)    #restore the return address
      addiu $sp,$sp,8    #pop
      jr   $ra           #return
```

$v0 = a0 * (a0 - 1)!$