



# Link Layer

# Link Layer


- Transfer frames over one or more connected links
  - Frames are messages of limited size
  - Builds on the physical layer which moves stream of bits




# In terms of layers ...



# In terms of layers ...



# Typical Implementation of Layers (2)



# Topics we'll cover


1. Framing
  - Delimiting start/end of frames
2. Error detection and correction
  - Handling errors
3. Multiple Access
  - 802.11, classic Ethernet
4. Switching
  - Modern Ethernet

# Framing

Delimiting start/end of frames

# Framing: Problem

- How do we interpret a stream of bits as a sequence of frames?



Ideas?



# Framing Methods


1. Fixed-size frames (motivation)
  2. Byte count (motivation)
  3. Byte stuffing
  4. Bit stuffing
- In practice, the physical layer often helps to identify frame boundaries
    - E.g., Ethernet, 802.11

# 1. Fixed-size frames

- Make every frame a fixed number of bits
  - Pad smaller frames
  
- Problems?
  - Wasted transmissions for small frames

## 2. Byte Count


- Start each frame with a length field



- Problems?

## 2. Byte Count: Problem

- Difficult to re-synchronize after framing error
  - Want a way to scan for a start of frame



### 3. Byte Stuffing


- A special flag byte value for start/end of frame
  - Replace (“stuff”) the flag with an escape code



- Problems?

# 3. Byte Stuffing: Problem

- Must escape the escape code too! Rules:
  - Replace each FLAG in data with ESC FLAG
  - Replace each ESC in data with ESC ESC



- Now any unescaped FLAG denotes frame start/end

# Unstuffing

You see:


1. Solitary FLAG?
2. Solitary ESC?
3. ESC FLAG?
4. ESC ESC FLAG?
5. ESC ESC ESC FLAG?
6. ESC FLAG FLAG?

What it means

- > Start or end of packet
- > Bad packet!
- > remove ESC and pass FLAG through
- > removed ESC and then start of end of packet
- > pass ESC FLAG through
- > pass FLAG through then start of end of packet

# 4. Bit Stuffing

- Can stuff at the bit level too
  - Call a flag six consecutive 1s
  - On transmit, after five 1s in the data, insert a 0
  - On receive, a 0 after five 1s is deleted






# Link Example: PPP over SONET

- PPP is Point-to-Point Protocol
- Widely used for link framing
  - E.g., it is used to frame IP packets that are sent over SONET optical links


# Link Example: PPP over SONET (2)

- Think of SONET as a bit stream, and PPP as the framing that carries an IP packet over the link



# Link Example: PPP over SONET (3)

- Framing uses byte stuffing
  - **FLAG** is 0x7E and **ESC** is 0x7D



# Link Example: PPP over SONET (4)


- Byte stuffing method:
  - To stuff (unstuff) a byte
    - add (remove) ESC (0x7D)
    - and XOR byte with 0x20
  - Removes **FLAG** from the contents of the frame

# Link Layer: Error detection and correction

# Problem: Noise may Flip Received Bits

- Link layers provides some protection
  - Detect errors with codes
  - Correct errors with codes
  - Retransmit lost frames ← Later
- Reliability concern cuts across the layers
  - E.g, TCP in the transport layer, DNS in the app layer

# Problem: Noise may Flip Received Bits



Ideas?

# Approach – Add Redundancy

- Error detection codes: Add check bits to the message bits to let some errors be detected
- Error correction codes: Add more check bits to let some errors be corrected
- Key issue: Structure the code such that
  - Need few check bits to detect/correct many errors
  - Modest computation



# Motivating Example


- A simple code to handle errors:
  - Send two copies! Error detected if different.
- How good is this code?
  - How many errors can it detect/correct?
  - How many errors will make it fail?

# Want to Handle More Errors w/ Fewer Bits

- We'll look at better codes (applied mathematics)
  - But, they can't handle all errors
  - And they focus on accidental (random) errors

# Using Error Codes

- Codeword consists of  $D$  data plus  $R$  check bits (=systematic block code)




- Sender:
  - Compute  $R$  check bits based on the  $D$  data bits; send the codeword of  $D+R$  bits

# Using Error Codes (2)


- Receiver:

- Receive  $D+R$  bits with unknown errors
- Recompute  $R$  check bits based on the  $D$  data bits
- Error detected if  $R$  doesn't match  $R'$



# Intuition for Error Codes


- For  $D$  data bits,  $R$  check bits:



- Randomly chosen  $D+R$  bits is unlikely to be correct
  - Low, controllable overhead

# R.W. Hamming (1915-1998)

- Much early work on codes:
  - “Error Detecting and Error Correcting Codes”, BSTJ, 1950
- See also:
  - “You and Your Research”, 1986



Source: IEEE GHN, © 2009 IEEE

# Hamming Distance

- Distance is the number of bit flips needed to change  $D_1$  to  $D_2$
- Hamming distance of a coding is the minimum error distance between any pair of codewords (bit-strings) that cannot be detected

# Hamming Distance (2)

- Error detection:
  - For a coding of distance  $d+1$ , up to  $d$  errors will always be detected
- Error correction:
  - For a coding of distance  $2d+1$ , up to  $d$  errors can always be corrected by mapping to the closest valid codeword



# Simple Error Detection – Parity Bit

- Take  $D$  data bits, add 1 check bit
  - Check bit could be sum modulo 2 or XOR

# Parity Bit (2)

- How well does parity work?
  - What is the distance of the code?
  - How many errors will it detect/correct?
- What about larger errors?

# Checksums

- Idea: sum up data in N-bit words
  - Widely used in, e.g., TCP/IP/UDP

1500 bytes	16 bits
------------	---------

- Stronger protection than parity

# Internet Checksum

- Sum is defined in 1s complement arithmetic (must add back carries)
  - And it's the negative sum
- *“The checksum field is the 16 bit one's complement of the one's complement sum of all 16 bit words ...”* – RFC 791

# Internet Checksum (2)

Sending:

1. Arrange data in 16-bit words
2. Put zero in checksum position, add
3. Add any carryover back to get 16 bits
4. Negate (complement) to get sum

0001  
f204  
f4f5  
f6f7

# Internet Checksum (3)

Sending:

1. Arrange data in 16-bit words
2. Put zero in checksum position, add
3. Add any carryover back to get 16 bits
4. Negate (complement) to get sum

$$\begin{array}{r} 0001 \\ \text{f}204 \\ \text{f}4\text{f}5 \\ \text{f}6\text{f}7 \\ + (0000) \\ \hline 2\text{d}\text{d}\text{f}1 \\ \downarrow \\ \text{d}\text{d}\text{f}1 \\ + \quad 2 \\ \hline \text{d}\text{d}\text{f}3 \\ \downarrow \\ 220\text{c} \end{array}$$

# Internet Checksum (4)

Receiving:

1. Arrange data in 16-bit words
2. Checksum will be non-zero, add
3. Add any carryover back to get 16 bits
4. Negate the result and check it is 0

```
0001
f204
f4f5
f6f7
+ 220c
-----
```

# Internet Checksum (5)

Receiving:

1. Arrange data in 16-bit words
2. Checksum will be non-zero, add
3. Add any carryover back to get 16 bits
4. Negate the result and check it is 0

$$\begin{array}{r} 0001 \\ f204 \\ f4f5 \\ f6f7 \\ + 220c \\ \hline 2fffd \\ \downarrow \\ \begin{array}{r} fffd \\ + 2 \\ \hline ffff \\ \downarrow \\ \mathbf{0000} \end{array} \end{array}$$



# Internet Checksum (6)

- How well does the checksum work?
  - What is the distance of the code?
  - How many errors will it detect/correct?