

Operating systems for embedded systems

- Embedded operating systems
 - How do they differ from desktop operating systems?
- Programming model
 - Process-based
 - Event-based
 - How is concurrency handled?
 - How are resource conflicts managed?
- Programming languages
 - C/C++
 - Java/C#
 - Memory management
 - Atomicity in the presence of interrupts

Embedded Operating Systems

- Features of all operating systems
 - Abstraction of system resources
 - Managing of system resources
 - Concurrency model
 - Launch applications
- Desktop operating systems
 - General-purpose – all features may be needed
 - Large-scale resources – memory, disk, file systems
- Embedded operating systems
 - Application-specific – just use features you need, save memory
 - Small-scale resources – sensors, communication ports

System Resources on Typical Sensor Nodes

- Timers
- Sensors
- Serial port
- Radio communications
- Memory
- Power management

Abstraction of System Resources

- Create virtual components
 - E.g., multiple timers from one timer
- Allow them to be shared by multiple threads of execution
 - E.g., two applications that want to share radio communication
- Device drivers provide interface for resource
 - Encapsulate frequently used functions
 - Save device state (if any)
 - Manage interrupt handling

Very simple device driver

- Turn LED on/off
- Parameters:
 - port pin
- API:
 - on(port_pin) - specifies the port pin (e.g., port D pin 3)
 - off(port_pin)
- Interactions:
 - only if other devices want to use the same port

Simple device driver

- Turning an LED on and off at a fixed rate
- Parameters:
 - port pin
 - rate at which to blink LED
- API:
 - on(port_pin, rate)
 - specifies the port pin (e.g., port D pin 3)
 - specifies the rate to use in setting up the timer (what scale?)
 - off(port_pin)
- Internal state and functions:
 - keep track of state (on or off) of each pin
 - interrupt service routine to handle timer interrupt

Interesting interactions

- What if other devices also need to use timer (e.g., PWM device)?
 - timer interrupts now need to be handled differently depending on which device's alarm is going off
- Benefits of special-purpose output compare peripheral
 - output compare pins used exclusively for one device
 - output compare has a separate interrupt handling routine
- What if we don't have output compare capability or run out of output compare units?

Sharing timers

- Create a new device driver for the timer unit
 - Allow other devices to ask for timer services
 - Manage timer independently so that it can service multiple requests
- Parameters:
 - Time to wait, address to call when timer reaches that value
- API:
 - `set_timer(time_to_wait, call_back_address)`
 - Set `call_back_address` to correspond to `time+time_to_wait`
 - Compute next alarm to sound and set timer
 - Update in interrupt service routine for next alarm
- Internal state and functions:
 - How many alarms can the driver keep track of?
 - How are they organized? FIFO? priority queue?

Concurrency

- Multiple programs interleaved as if parallel
- Each program requests access to devices/services
 - e.g., timers, serial ports, etc.
- Exclusive or concurrent access to devices
 - allow only one program at a time to access a device (e.g., serial port)
 - arbitrate multiple accesses (e.g., timer)
- State and arbitration needed
 - keep track of state of devices and concurrent programs using resource
 - arbitrate their accesses (order, fairness, exclusivity)
 - monitors/locks (supported by primitive operations in ISA - test-and-set)
- Interrupts
 - disabling may effect timing of programs
 - keeping enabled may cause unwanted interactions

Handling concurrency

- Traditional operating system
 - multiple threads or processes
 - file system
 - virtual memory and paging
 - input/output (buffering between CPU, memory, and I/O devices)
 - interrupt handling (mostly with I/O devices)
 - resource allocation and arbitration
 - command interface (execution of programs)
- Embedded operating system
 - lightweight threads
 - input/output
 - interrupt handling
 - real-time guarantees

Embedded operating systems

- Lightweight threads
 - basic locks
 - fast context-switches
- Input/output
 - API for talking to devices
 - buffering
- Interrupt handling (with I/O devices and UI)
 - translate interrupts into events to be handled by user code
 - trigger new tasks to run (reactive)
- Real-time issues
 - guarantee task is called at a certain rate
 - guarantee an interrupt will be handled within a certain time
 - priority or deadline driven scheduling of tasks

Some Examples

- WindowsCE/WindowsMobile
 - PDA operating system
 - spin-off of Windows NT
 - portable to a wide variety of processors (e.g., Xscale)
 - full-featured OS modularized to only include features as needed
- Wind River Systems VxWorks
 - one of the most popular embedded OS kernels
 - highly portable to an even wider variety of processors (tiny to huge)
 - modularized even further than the ones above (basic system under 50K)
- TinyOS
 - Open-source development environment specificall for small sensors
 - Simple (and tiny) operating system
 - Scheduler/event model of concurrency
 - Software components for efficient modularity
 - Software encapsulation for resources of sensor networks
 - Programming language and model – nesC

embedded operating systems typically reside in ROM (flash) - changed rarely

Embedded Linux

- iMote2 supports Linux, TinyOS, and SOS
 - Linux is the Familiar release originally developed for iPAQs (actually the DEC Itsy PDA by DEC Western Research Lab and then by Compaq's Cambridge lab)
- Linux kernel provides many utilities
 - Timer abstractions
 - File system
 - Serial communication
 - IP network communication
 - Memory management
- We can extend the kernel by registering new modules
 - These can control the internal registers of the XScale microcontroller

A Simple Application

- Blinking an LED at 1Hz – Lab 1 revisited
- Module to control LED GPIO pin
 - Sets state of LED
 - Uses timer
 - API allows setting of blink rate
- Register module in kernel
 - Assigned a “device number” by the Linux OS
- User-level application calls module API to start/stop/set

Kernel module

```
#include <linux/module.h>
#include <linux/init.h>
#include <linux/fs.h>
#include <linux/cdev.h>
#include <linux/errno.h>
#include <linux/interrupt.h>
#include <asm/hardware.h>
#include <asm-arm/arch-pxa/pxa-regs.h> // This include file lets us access memory-mapped I/O registers
#include "blink.h"

#define OIER_E4      (1<<4)
#define RED         (1<<7)

dev_t devId; // Contains the major and minor device numbers
struct cdev *cdev; // A kernel character device struct
int blink_ioctl(struct inode *, struct file *, unsigned int, unsigned long);
static void __exit unload_function(void);
struct file_operations blink_fops = {.owner = THIS_MODULE, .ioctl = blink_ioctl};

int state = 0; // State of the LED (on or off)
int delay = 16384; // Period is 1/16384 seconds * delay

int blink_ioctl(struct inode *inode, struct file *filp, unsigned int cmd, unsigned long arg) {
    switch (cmd) {
        case BLINK_SET_RATE:
            OSMR4 = arg; // Update the match register
            OSC4 = 0; // Reset the counter
            break;
        default:
            return -ENOTTY;
    }
    return 0;
}
```

Kernel module (cont'd)

```
irqreturn_t blink_irq_handler(int irq, void *dev_id, struct pt_regs *regs) // called by kernel
{
    // Check to see if this interrupt is for us
    if (!(OSSR & OIER_E4))
        return IRQ_RETVAL(IRQ_NONE);
    OSSR = OIER_E4; // Acknowledge this interrupt
    state = !state;
    if (state)
        GPCR3 = RED;
    else
        GPCR3 = RED;
    return IRQ_RETVAL(IRQ_HANDLED);
}

static int __init init_function(void) // discardable by kernel
{
    int result;
    // Allocate a major device number for this driver
    result = alloc_chrdev_region(&devId, 0, 1, "blink");
    if (result < 0) return result;
    // Allocate a character device and set the owner and file operations of this new character device
    cdev = cdev_alloc();
    cdev->owner = THIS_MODULE;
    cdev->ops = &blink_fops;
    // Register the character device
    // Note at this point the device is live!
    result = cdev_add(cdev, devId, 1);
    result = request_irq(IRQ_OST_4_11, blink_irq_handler, 0, "blink", cdev);
    if (result < 0) {
        unload_function();
        return result;
    }
    // At this point, everything should succeed, so initialize the hardware
    OMC4 = 0xC9; // Match against channel 4, periodic timer, reset on match,
    // period is 1 microsecond.
    OSMR4 = delay;
    OIER |= OIER_E4; // Enable interrupts for channel 4
    OSC4 = 0; // Start the counter
    return 0; // SUCCESS
}
```


Kernel module (cont'd)

```
static void __exit unload_function(void)
{
    // Turn off interrupts
    OIER &= ~OIER_E4;
    free_irq(IRQ_OST_4_11, cdev);

    // Free the character device
    cdev_del(cdev);
    // Unregister the major device number
    unregister_chrdev_region(devId, 1);
}

// These two macros let the compiler and kernel know which functions
// should be called when loading and unloading this module.
module_init(init_function);
module_exit(unload_function);
```

Application

```
#include <sys/types.h>
#include <sys/stat.h>
#include <fcntl.h>
#include <unistd.h>
#include <stdio.h>
#include "blink.h"

int main(int argc, char *argv)
{
    int rate, fd;

    if (argc != 2) {
        printf("Usage: %s <Hz>\n", argv[0]);
        return 0;
    }

    rate = (int)(16384 / atof(argv[1]));

    fd = open("/dev/blink", O_WRONLY);
    if (fd < 0) {
        printf("Unable to open /dev/blink\n");
        return 0;
    }

    ioctl(fd, BLINK_SET_RATE, rate);
    close(fd);
}
```

Labs 5 and 6

- Lab 5
 - Familiarize with iMote2 programming
 - Communicate with sensor over SPI
 - Use accelerometer to control tri-color LED

- Lab 6
 - Add “SuperBird” board to your iMote2
 - Learn to use some of the devices on the SuperBird
 - Map accelerometer to LCD (2D moving spot)
 - Map accelerometer to sounds (pitch and volume)
 - Use 802.15.4 radio to communicate accel of one board to another
 - Packet formats and API provided – define your own payload

