

Number systems

- ◆ Last lecture
 - Course overview
 - The Digital Age
- ◆ Today's lecture
 - Binary numbers
 - Base conversion
 - Number systems
 - Twos-complement
 - A/D and D/A conversion

Digital

- ◆ Digital = discrete
 - Binary codes (example: BCD)
 - Decimal digits 0-9
 - DNA nucleotides
- ◆ Binary codes
 - Represent symbols using binary digits (bits)
- ◆ Digital computers:
 - I/O is digital
 - ASCII, decimal, etc.
 - Internal representation is binary
 - Process information in bits

<u>Decimal Symbols</u>	<u>BCD Code</u>
0	0000
1	0001
2	0010
3	0011
4	0100
5	0101
6	0110
7	0111
8	1000
9	1001

The basics: Binary numbers

- ◆ Bases we will use
 - Binary: Base 2
 - Octal: Base 8
 - Hexadecimal: Base 16
- ◆ Positional number system
 - $101_2 = 1 \times 2^2 + 0 \times 2^1 + 1 \times 2^0$
 - $63_8 =$
 - $A1_{16} =$
- ◆ Addition and subtraction

$$\begin{array}{r} 1011 \\ + 1010 \\ \hline \end{array} \qquad \begin{array}{r} 1011 \\ - 0110 \\ \hline \end{array}$$

Binary → hex/decimal/octal conversion

- ◆ Conversion from binary to octal/hex
 - Binary: 10011110001
 - Octal:
 - Hex:
- ◆ Conversion from binary to decimal
 - $101_2 = 1 \times 2^2 + 0 \times 2^1 + 1 \times 2^0 = 5_{10}$
 - $63.4_8 =$
 - $A1_{16} =$

Decimal → binary/octal/hex conversion

Binary

Quotient Remainder

$56 \div 2 =$	28	0
$28 \div 2 =$	14	0
$14 \div 2 =$	7	0
$7 \div 2 =$	3	1
$3 \div 2 =$	1	1
$1 \div 2 =$	0	1

Octal

Quotient Remainder

$56 \div 8 =$	7	0
$7 \div 8 =$	0	7

$$56_{10} = 111000_2$$

$$56_{10} = 70_8$$

- ◆ Why does this work?
 - $N = 56_{10} = 111000_2$
 - $Q = N/2 = 56/2 = 111000/2 = 11100$ remainder 0
- ◆ Each successive divide liberates an LSB

Number systems

- ◆ How do we write negative binary numbers?
- ◆ Historically: 3 approaches
 - Sign-and-magnitude
 - Ones-complement
 - Twos-complement
- ◆ For all 3, the most-significant bit (msb) is the sign digit
 - $0 \equiv$ positive
 - $1 \equiv$ negative
- ◆ Learn twos-complement
 - Simplifies arithmetic
 - Used almost universally

Sign-and-magnitude

- ◆ The most-significant bit (msb) is the sign digit
 - 0 \equiv positive
 - 1 \equiv negative
- ◆ The remaining bits are the number's magnitude
- ◆ Problem 1: Two representations for zero
 - 0 = 0000 and also $-0 = 1000$
- ◆ Problem 2: Arithmetic is cumbersome

Add

Subtract

Compare and subtract

4	0100	4	0100	0100	- 4	1100	1100
+ 3	+ 0011	- 3	+ 1011	- 0011	+ 3	+ 0011	- 0011

Ones-complement

- ◆ Negative number: Bitwise complement positive number
 - $0011 \equiv 3_{10}$
 - $1100 \equiv -3_{10}$

- ◆ Solves the arithmetic problem

Add	Invert, add, add carry	Invert and add
$\begin{array}{r} 4 \quad 0100 \\ + 3 \quad + 0011 \end{array}$	$\begin{array}{r} 4 \quad 0100 \\ - 3 \quad + 1100 \end{array}$	$\begin{array}{r} - 4 \quad 1011 \\ + 3 \quad + 0011 \end{array}$

- ◆ Remaining problem: Two representations for zero
 - $0 = 0000$ and also $-0 = 1111$

Twos-complement

- ◆ Negative number: Bitwise complement **plus one**

- $0011 \equiv 3_{10}$

- $1101 \equiv -3_{10}$


- ◆ Number wheel

- ◆ Only one zero!

- ◆ msb is the sign digit

- $0 \equiv$ positive

- $1 \equiv$ negative



Twos-complement (con't)

- ◆ Complementing a complement → the original number
- ◆ Arithmetic is easy
 - Subtraction = negation and addition
 - ⇒ Easy to implement in hardware



Add		Invert and add		Invert and add	
4	0100	4	0100	- 4	1100
+ 3	+ 0011	- 3	+ 1101	+ 3	+ 0011

Miscellaneous

- ◆ Twos-complement of non-integers
 - $1.6875_{10} = 01.1011_2$
 - $-1.6875_{10} = 10.0101_2$
- ◆ Sign extension
 - Write +6 and -6 as twos complement
 - ⇒ 0110 and 1010
 - Sign extend to 8-bit bytes
 - ⇒ 00000110 and 11111010
- ◆ Can't infer a representation from a number
 - 11001 is 25 (unsigned)
 - 11001 is -9 (sign magnitude)
 - 11001 is -6 (ones complement)
 - 11001 is -7 (twos complement)

Twos-complement overflow

- ◆ Summing two positive numbers gives a negative result
- ◆ Summing two negative numbers gives a positive result



Twos-complement overflow (cont'd)

◆ Correct results

1111	-1		0011	+3
+ 1010	-6		+ 0010	+2

◆ Incorrect results

0110	+6		1001	-7
+ 0100	+4		+ 1010	-6

◆ Overflow condition

- Carry from 2sb-msb and carry from msb-Cout are different

2sb-msb	msb-Cout	Overflow
0	0	0
0	1	1
1	0	1
1	1	0

Gray and BCD codes

<u>Decimal Symbols</u>	<u>Gray Code</u>
0	0000
1	0001
2	0011
3	0010
4	0110
5	0111
6	0101
7	0100
8	1100
9	1101


<u>Decimal Symbols</u>	<u>BCD Code</u>
0	0000
1	0001
2	0010
3	0011
4	0100
5	0101
6	0110
7	0111
8	1000
9	1001

The physical world is analog

- ◆ Digital systems need to
 - Measure analog quantities
 - ⇒ Speech waveforms, etc
 - Control analog systems
 - ⇒ Drive motors, etc
- ◆ How do we connect the analog and digital domains?
 - Analog-to-digital converter (ADC or A/D)
 - ⇒ Example: CD recording
 - Digital-to-analog converter (DAC or D/A)
 - ⇒ Example: CD playback

Sampling

- ◆ **Quantization**
 - Conversion from analog to discrete values
- ◆ Quantizing a signal
 - We sample it



Signal Sampling

Datel Data Acquisition and Conversion Handbook


Conversion

◆ Encoding

- Assigning a digital word to each discrete value

◆ Encoding a quantized signal

- Encode the samples
- Typically Gray or binary codes



Transfer Function of Ideal 3-Bit Quantizer

Datel Data Acquisition and
Conversion Handbook