

CSE 451: Operating Systems  
Autumn 2010

Module 2  
Architectural Support for  
Operating Systems

Ed Lazowska  
lazowska@cs.washington.edu  
570 Allen Center

Even coarse architectural trends  
impact tremendously the design of systems

- Processing power
  - doubling every 18 months
  - 60% improvement each year
  - factor of 100 every decade
- 1980: 1 MHz Apple II+ = \$2,000 (~\$5,000 today)
  - 1980 also 1 MIPS VAX-11/780 = \$120,000 (~\$300,000 today)
- 2006: 3.0GHz Pentium D = \$800
- 2010: 3.0GHz Dual Core = \$500



Even coarse architectural trends  
impact tremendously the design of systems

- Processing power
  - doubling every 18 months
  - 60% improvement each year
  - factor of 100 every decade
- 1980: 1 MHz Apple II+ = \$2,000 (~\$5,000 today)
  - 1980 also 1 MIPS VAX-11/780 = \$120,000 (~\$300,000 today)
- 2006: 3.0GHz Pentium D = \$800
- 2010: 3.0GHz Dual Core = \$500



Power Consumption





Figure 2: Normalized Power versus Normalized Scalar Performance for Multiple Generations of Intel Microprocessors

<http://www.intel.com/pressroom/kits/core2duo/pdf/epi-trends-final2.pdf>

Primary Memory / Disk Capacity



San Jose Research Center © Hitachi Global Storage Technologies

- Primary memory cost
  - 1972: 1MB = \$1,000,000
  - 1982: I remember pulling all kinds of strings to get a special deal: 512K of VAX-11/780 memory for \$30,000
  - 2005:

- 2007:

10/16/2010 © 2010 Gribble, Lazowska, Levy, Zahorjan 7

- Today:

10/16/2010 © 2010 Gribble, Lazowska, Levy, Zahorjan 8

- Disk cost:
  - Only a few years ago, we purchased disks by the megabyte (and it hurt!)
  - Today, 1 GB (a billion bytes) costs \$1, \$0.50, \$0.25 from Dell (except you have to buy in increments of 40, 80, 250 GB)
    - => 1 TB costs \$1K, \$50K, \$250, 1 PB costs \$1M, \$500K, \$250K

10/16/2010 © 2010 Gribble, Lazowska, Levy, Zahorjan 9

- Aside: Where does it all go?
  - Facetiously: "What Gordon giveth, Bill taketh away"
  - Realistically: our expectations for what the system will do increase relentlessly
    - e.g., GUI
  - "Software is like a gas – it expands to fill the available space" – Nathan Myhrvold (1960-)

10/16/2010 © 2010 Gribble, Lazowska, Levy, Zahorjan 10


### Primary Memory Bandwidth

10/16/2010 © 2010 Gribble, Lazowska, Levy, Zahorjan 11

- Optical bandwidth today
  - Doubling every 9 months
  - 150% improvement each year
  - Factor of 10,000 every decade
    - 10x as fast as disk capacity!
    - 100x as fast as processor performance!!
- What are some of the implications of these trends?
  - Just one example: We have always designed systems so that they "spend" processing power in order to save "scarce" storage and bandwidth!

10/16/2010 © 2010 Gribble, Lazowska, Levy, Zahorjan 12

## Storage Latency: How Far Away is the Data?



© 2004 Jim Gray, Microsoft Corporation

## A Current Trend: Solid State Disks




Figure B: HDD and SSD Storage Price Trend (2004-2009), cents / MByte  
Source: Intel and Research




Figure C: 3.3 inch Flash SSD Sustained Random Read/Write Rates Trend

<http://www.embeddedstar.com/articles/2005/2/article20050207-4.html>

10/16/2010

© 2010 Gribble, Lazowska, Levy, Zahorjan


14



10/16/2010

© 2010 Gribble, Lazowska, Levy, Zahorjan


15



10/16/2010

© 2010 Gribble, Lazowska, Levy, Zahorjan

16



10/16/2010

© 2010 Gribble, Lazowska, Levy, Zahorjan

17

## Lower-level architecture affects the OS even more dramatically

- The operating system supports sharing and protection
  - multiple applications can run concurrently, sharing resources
  - a buggy or malicious application can't nail other applications or the system
- There are many approaches to achieving this
- The architecture determines which approaches are viable (reasonably efficient, or even possible)
  - includes instruction set (synchronization, I/O, ...)
  - also hardware components like MMU or DMA controllers

10/16/2010

© 2010 Gribble, Lazowska, Levy, Zahorjan

18

- Architectural support can vastly simplify (or complicate!) OS tasks
  - e.g.: early PC operating systems (DOS, MacOS) lacked support for virtual memory, in part because at that time PCs lacked necessary hardware support
    - Apollo workstation used two CPUs as a bandaid for non-restartable instructions!
  - Until very recently, Intel-based PCs still lacked support for 64-bit addressing (which has been available for a decade on other platforms: MIPS, Alpha, IBM, etc...)
    - changing rapidly due to AMD's 64-bit architecture

10/16/2010

© 2010 Gribble, Lazowska, Levy, Zahorjan

19

## Architectural features affecting OS's

- These features were built primarily to support OS's:
  - timer (clock) operation
  - synchronization instructions (e.g., atomic test-and-set)
  - memory protection
  - I/O control operations
  - interrupts and exceptions
  - protected modes of execution (kernel vs. user)
  - privileged instructions
  - system calls (and software interrupts)
  - virtualization architectures
    - Intel: <http://www.intel.com/technology/itj/2006/v10i3/1-hardware/7-architecture-usage.htm>
    - AMD: <http://sites.amd.com/us/business/it-solutions/usage-models/virtualization/Pages/amd-v.aspx>

10/16/2010

© 2010 Gribble, Lazowska, Levy, Zahorjan

20

## Privileged/Protected instructions

- some instructions are restricted to the OS
  - known as **protected** or **privileged** instructions
- e.g., only the OS can:
  - directly access I/O devices (disks, network cards)
    - why?
  - manipulate memory state management
    - page table pointers, TLB loads, etc.
    - why?
  - manipulate special 'mode bits'
    - interrupt priority level
    - why?

10/16/2010

© 2010 Gribble, Lazowska, Levy, Zahorjan

21

## OS protection

- So how does the processor know if a privileged instruction should be executed?
  - the architecture must support at least two modes of operation: **kernel** mode and **user** mode
    - VAX, x86 support 4 protection modes
  - mode is set by status bit in a protected processor register
    - user programs execute in user mode
    - OS executes in kernel (privileged) mode (OS == kernel)
- Privileged instructions can only be executed in kernel (privileged) mode
  - what happens if code running in user mode attempts to execute a privileged instruction?

10/16/2010

© 2010 Gribble, Lazowska, Levy, Zahorjan

22

## Crossing protection boundaries

- So how do user programs do something privileged?
  - e.g., how can you write to a disk if you can't execute an I/O instructions?
- User programs must call an OS procedure – that is, get the OS to do it for them
  - OS defines a set of **system calls**
  - User-mode program executes system call instruction
- Syscall instruction
  - Like a **protected** procedure call

10/16/2010

© 2010 Gribble, Lazowska, Levy, Zahorjan

23


- The syscall instruction atomically:
  - Saves the current PC
  - Sets the execution mode to privileged
  - Sets the PC to a handler address
- With that, it's a lot like a local procedure call
  - Caller puts arguments in a place callee expects (registers or stack)
    - One of the args is a syscall number, indicating which OS function to invoke
  - Callee (OS) saves caller's state (registers, other control state) so it can use the CPU
  - OS function code runs
    - OS must verify caller's arguments (e.g., pointers)
  - OS returns using a special instruction
    - Automatically sets PC to return address and sets execution mode to user

10/16/2010

© 2010 Gribble, Lazowska, Levy, Zahorjan

24

## A kernel crossing illustrated



## System call issues

- What would be wrong if a syscall worked like a regular subroutine call, with the caller specifying the next PC?
- What would happen if kernel didn't save state?
- Why must the kernel verify arguments?
- How can you reference kernel objects as arguments to or results from system calls?

10/16/2010 © 2010 Gribble, Lazowska, Levy, Zahorjan 26


## Exception Handling and Protection

- All entries to the OS occur via the mechanism just shown
  - Acquiring privileged mode and branching to the trap handler are inseparable
- Terminology:
  - **Interrupt**: asynchronous; caused by an external device
  - **Exception**: synchronous; unexpected problem with instruction
  - **Trap**: synchronous; intended transition to OS due to an instruction
- Privileged instructions and resources are the basis for most everything: memory protection, protected I/O, limiting user resource consumption, ...

10/16/2010 © 2010 Gribble, Lazowska, Levy, Zahorjan 27

## Memory protection

- OS must protect user programs from each other
  - maliciousness, ineptitude
- OS must also protect itself from user programs
  - integrity and security
  - what about protecting user programs from OS?
- Simplest scheme: **base and limit registers**
  - are these protected?



base and limit registers are loaded by OS before starting program

10/16/2010 © 2010 Gribble, Lazowska, Levy, Zahorjan 28

## More sophisticated memory protection

- coming later in the course
- paging, segmentation, virtual memory
  - page tables, page table pointers
  - translation lookaside buffers (TLBs)
  - page fault handling

10/16/2010 © 2010 Gribble, Lazowska, Levy, Zahorjan 29

## I/O control

- Issues:
  - how does the OS start an I/O?
    - special I/O instructions
    - memory-mapped I/O
  - how does the OS notice an I/O has finished?
    - polling
    - interrupts
  - how does the OS exchange data with an I/O device?
    - Programmed I/O (PIO)
    - Direct Memory Access (DMA)

10/16/2010 © 2010 Gribble, Lazowska, Levy, Zahorjan 30

## Asynchronous I/O

- Interrupts are the basis for asynchronous I/O
  - device performs an operation asynchronously to CPU
  - device sends an interrupt signal on bus when done
  - in memory, a **vector table** contains list of addresses of kernel routines to handle various interrupt types
    - who populates the vector table, and when?
  - CPU switches to address indicated by vector index specified by interrupt signal
- What's the advantage of asynchronous I/O?

10/16/2010

© 2010 Gribble, Lazowska, Levy, Zahorjan

31

## Timers

- How can the OS prevent runaway user programs from hogging the CPU (infinite loops?)
  - use a hardware timer that generates a periodic interrupt
  - before it transfers to a user program, the OS loads the timer with a time to interrupt
    - “quantum” – how big should it be set?
  - when timer fires, an interrupt transfers control back to OS
    - at which point OS must decide which program to schedule next
    - very interesting policy question: we'll dedicate a class to it
- Should access to the timer be privileged?
  - for reading or for writing?

10/16/2010

© 2010 Gribble, Lazowska, Levy, Zahorjan

32

## Synchronization

- Interrupts cause a wrinkle:
  - may occur any time, causing code to execute that interferes with code that was interrupted
  - OS must be able to **synchronize** concurrent processes
- Synchronization:
  - guarantee that short instruction sequences (e.g., read-modify-write) execute atomically
  - one method: turn off interrupts before the sequence, execute it, then re-enable interrupts
    - architecture must support disabling interrupts
      - Privileged???
  - another method: have special complex atomic instructions
    - read-modify-write
    - test-and-set
    - load-linked store-conditional

10/16/2010

© 2010 Gribble, Lazowska, Levy, Zahorjan

33

## “Concurrent programming”

- Management of concurrency and asynchronous events is biggest difference between “systems programming” and “traditional application programming”
  - modern “event-oriented” application programming is a middle ground
- Arises from the architecture
  - Can be sugar-coated, but cannot be totally abstracted away
- Huge intellectual challenge
  - Unlike vulnerabilities due to buffer overruns, which are just sloppy programming

10/16/2010

© 2010 Gribble, Lazowska, Levy, Zahorjan

34

## Architectures are still evolving

- New features are still being introduced to meet modern demands
  - Support for virtual machine monitors
  - Hardware transaction support (to simplify parallel programming)
  - Support for security (encryption, trusted modes)
  - Increasingly sophisticated video / graphics
  - Other stuff that hasn't been invented yet...
- In current technology transistors are free – CPU makers are looking for new ways to use transistors to make their chips more desirable
- Intel's big challenge: finding applications that require new hardware support, so that you will want to upgrade to a new computer to run them

10/16/2010

© 2010 Gribble, Lazowska, Levy, Zahorjan

35

## Some questions

- Why wouldn't you want a user program to be able to access an I/O device (e.g., the disk) directly?
- OK, so what keeps this from happening? What prevents user programs from directly accessing the disk?
- So, how does a user program cause disk I/O to occur?
- What prevents a user program from scribbling on the memory of another user program?
- What prevents a user program from scribbling on the memory of the operating system?
- What prevents a user program from running away with the CPU?

10/16/2010

© 2010 Gribble, Lazowska, Levy, Zahorjan

36