





II. Control system terminology

- ◆ Input - stimulus from external source/sensor.
 - ◆ Output - response of the system.
 - ◆ Feedback - output sample used to modify performance of the system.
- 




II. Control system terminology


- ◆ Error - difference between input and feedback.
 - ◆ Open-loop control - control action based on input independent of output.
 - ◆ Closed-loop control - control action is dependent on output of system.
 - ◆ Advantage of closed-loop: system controls accuracy of the output for self regulation
- 

III. Characteristics


- ◆ Position Feedback: employed to make the output exactly follow the input where a linear or angular displacement is desired.
- ◆ Rate feedback: used to smooth a motion or displacement and to restrict the velocity of the output.
- ◆ Acceleration feedback: further restriction to change in velocity of system which, together with velocity, prevent overshoot and oscillation (smooth motion).


IV. Control system block diagram






IV. Control system building blocks


- ◆ Control Element (G): math model of system components without f/b
 - ◆ Summing point: (+) or (-) two or more signals
 - ◆ Splitting point: sampling point => outputs = inputs
 - ◆ Input (r = reference):
- 



IV. Control system building blocks


- ◆ Control output(c):
 - ◆ Error signal (e): difference between input and f/b
 - ◆ Feedback element (H):
 - ◆ Feedback signal (b):
- 

V. Control system block diagram




VI. Response in feedback control systems

- ◆ No damping - rapid and continuous oscillation, neglecting friction.
- ◆ Underdamping: rapidly overshoots the desired output and oscillates about the desired value. The frequency of oscillation is reduced slowly. (quick response, long oscillations).



VI. Response in feedback control systems

- ◆ Overdamping: slowly achieves desired level with no overshoot (very slow response, no oscillations).
- ◆ Critical damping: exhibits the minimum response time possible without overshooting desired new position (fair response time, and no overshoot).



VI. Response in feedback control systems

- ◆ Realistic systems: usually slightly underdamped to get rapid response, minimum overshoot.

